

SD058 - Class 20 Diesel

F#	Spot Sound Description	Mode								
F0	Headlight/Rear Lights	T								
F1	Sound Enable/Engine Start	T								
F2	Multiple Horns	M	F2a_20_Hi	F2b_20_Hi_Lo	F2c_20_Lo	F2d_20_Lo_Hi	F2e_20_Lo_Lo	F2f_20_Lo_Quick_High	UNUSED	UNUSED
F3	Multiple Horns Fancy	M	F3a_20_Approach_Hi_Lo_Hi	F3b_20_Hi_Lo_2	F3c_20_HI_Lo_Hi	F3d_20_Hi_Lo_Lo_2	F3e_20_Hi_Lo_Lo_Hi	F3f_20_Slow_HI_Lo_Hi	UNUSED	UNUSED
F4	Brake	M								
F5	Notch up	M								
F6	Notch Down	M								
F7	Return to Idle	M								
F8	Thrash	T								
F9	Diesel Cold Start override operation of F1, until disabled.	T								
F10	Destroying Vacuum	T								
F11	Spirax Valve	T								
F12	Cooling Fan	T								
F13	Primer	T								
F14	Flange Squeal	M								
F15	Brake Release	M								
F16	Door Slam	M								
F17	Buffer Up	M								
F18	Coupling	M								
F19	Guards Whistle	M								
F20	Wagons Clanging	M								
F21	Aux1	T								
F22	Aux2	T								
F23	Aux 3	T								
F24	Aux 4	T								
F25	Shunt Mode	M								
F26	Creep Mode	M								
F27	Dynamic Brake	M	M = Momentary Action							
F28	AFC Enable	T	T = Toggle On/Off							

Please refer to the main HM7000 Series Decoder Reference Manual for further information