

SD015 - Class 67 Diesel

F#	Spot Sound Description	Mode							
F0	Headlight/Rear Lights	T							
F1	Sound Enable/Engine Start	T							
F2	Multiple Horns	M	F2a_67_High_Low	F2b_67_Low_High	F2c_67_Low_Low_Low	F2d_67_Low_Low_High	F2e_67_Low_High_High_Low	F2f_67_Low_Short	F2g_67_Low_Low_Short
F3	Multiple Horns Fancy	M	F3a_67_Low_Low_Low_High_Low	F3b_67_High_Low_Very_Long	F3c_67_Fancy_1	F3d_67_Fancy_2	F3e_67_Low_High_Low_Long	F3f_67_Low_High_Low_High_Low	
F4	Brake	M							
F5	Notch up	M							
F6	Notch Down	M							
F7	Return to Idle	M							
F8	Thrash	T							
F9	Diesel Cold Start override operation of F1, until disabled.	T							
F10	Compressor (Manual)	T							
F11	Cooling Fan	T							
F12	Spirax Valve	T							
F13	Carriage Brake Squeal	M							
F14	Flange Squeal	T							
F15	Cab Door Close	M							
F16	Buffering	M							
F17	AWS Warning	M							
F18	Guards Whistle	M							
F19	Coupling	M							
F20	Carriages Passing	T							
F21	Aux1	T							
F22	Aux2	T							
F23	Aux 3	T							
F24	Aux 4	T							
F25	Shunt Mode	M							
F26	Creep Mode	M							
F27	Dynamic Brake	M	M = Momentary Action						
F28	AFC Enable	T	T = Toggle On/Off						

Please refer to the main HM7000 Series Decoder Reference Manual for further information