

SD032 - Class 55 Diesel

F#	Spot Sound Description	Mode								
F0	Headlight/Rear Lights	T								
F1	Sound Enable/Engine Start	T								
F2	Multiple Horns	M	F2a_High_Low	F2b_Low_High	F2c_High_Low	F2d_Low_High	F2e_2_Bursts	UNUSED	UNUSED	UNUSED
F3	Multiple Horns Fancy	M	F3a_Fancy	F3b_Multi_Tone	UNUSED	UNUSED	UNUSED	UNUSED	UNUSED	UNUSED
F4	Brake	M								
F5	Notch up	M								
F6	Notch Down	M								
F7	Return to Idle	M								
F8	Thrash	T								
F9	Diesel Cold Start override operation of F1, until disabled.	T								
F10	Compressor (Manual)	T								
F11	Windscreen Wipers	T								
F12	Spirax Valve	T								
F13	Carriage Brake Squeal	M								
F14	Flange Squeal	T								
F15	Brake Release	M								
F16	Passing Carriages	T								
F17	Coupling	M								
F18	Sound Guards Whistle	M								
F19	Wagons Buffering	M								
F20	Cab Door	M								
F21	Aux1	T								
F22	Aux2	T								
F23	Aux 3	T								
F24	Aux 4	T								
F25	Creep Mode	M								
F26	Coupling Mode	M								
F27	Dynamic Brake	M	M = Momentary Action							
F28	AFC Enable	T	T = Toggle On/Off							

Please refer to the main HM7000 Series Decoder Reference Manual for further information