

SD041 - TT Class 43 Valenta Diesel

F#	Spot Sound Description	Mode									
F0	Headlight/Rear Lights	T									
F1	Sound Enable/Engine Start	T									
F2	Multiple Horns	M	F2a_43v_Low_High_Short	F2b_43v_High_Low_Short	F2c_43v_High_Low_Medium	F2d_43v_Low_High_Medium	UNUSED	UNUSED	UNUSED	UNUSED	
F3	Multiple Horns Fancy	M	F3a_43v_Low_High_Long_Distant	F3b_43v_High_Low_Fancy_Long	F3c_43v_Fancy_Multiple	F3d_43v_High_Low_High	UNUSED	UNUSED	UNUSED	UNUSED	
F4	Brake	M									
F5	Notch up	M									
F6	Notch Down	M									
F7	Return to Idle	M									
F8	Thrash	T									
F9	Diesel Cold Start override operation of F1, until disabled.	T									
F10	Compressor (Manual)	T									
F11	Windscreen Wipers	T									
F12	Roof Fan (Manual Operation)	T									
F13	Guard to Driver Buzzer	M									
F14	Flange Squeal	T									
F15	Cab Door Shut	M									
F16	Primer	T									
F17	Firebell Test	M									
F18	Guards Whistle	M									
F19	Automatic Warning System Test	M									
F20	Drivers Safety Beeper	M									
F21	*Cab Light	T									
F22	Aux2	T									
F23	Aux 3	T									
F24	Aux 4	T									
F25	Shunt Mode	M									
F26	Creep Mode	M									
F27	Dynamic Brake	M	M = Momentary Action								
F28	AFC Enable	T	T = Toggle On/Off								

*NOTE - F21 Cab Light only works when the loco is stationary. It will automatically switch off when in motion.

Please refer to the main HM7000 Series Decoder Reference Manual for further information