

### SD508 - Mistral 69' Generator Van (Diesel)

F#	Spot Sound Description	Mode								
F0	Headlight/Rear Lights	T								
F1	Sound Enable/Engine Start	T								
F2	Multiple Horns (5)	M	F2a_Low_High_Short	F2b_High_Low_Short	F2c_Low_Low_Low_Short	F2d_High_Low_High_Short	F2e_Low_Low_High_Short	UNUSED	UNUSED	UNUSED
F3	Multiple Horns Fancy (3)	M	F3a_High_Low_High_Long	F3b_Fancy_1	F3c_Fancy_2	UNUSED	UNUSED	UNUSED	UNUSED	UNUSED
F4	Brake	M								
F5	Notch up	M								
F6	Notch Down	M								
F7	Return to Idle	M								
F8	Thrash	T								
F9	Diesel Cold Start override operation of F1, until disabled.	T								
F10	Doors Open / Close	T								
F11	Coupling	M								
F12	Air Brake Hose Coupling	M								
F13	Guards Whistle	M								
F14	NOT USED	M								
F15	NOT USED	M								
F16	NOT USED	M								
F17	NOT USED	M								
F18	NOT USED	M								
F19	NOT USED	M								
F20	NOT USED	M								
F21	Aux 1 - Rear Red Lights	T								
F22	Aux 2	T								
F23	Aux 3	T								
F24	Aux 4	T								
F25	Shunting Mode	T								
F26	Creep Mode	M								
F27	Dynamic Brake	M	<b>M = Momentary Action</b>							
F28	AFC Enable	T	<b>T = Toggle On/Off</b>							

Please refer to the main HM7000 Series Decoder Reference Manual for further information