

### SD010 - A1 Class Tornado Steam

F#	Spot Sound Description	Mode								
F0	Headlight/Rear Lights (If fitted)	T								
F1	Sound On / Off	T								
F2	Multiple Whistles A1 (4)	M	F2a_Long_A1	F2b_Toot_Toot	F2c_Medium_Burst	F2d_Long_Fancy	UNUSED	UNUSED	UNUSED	UNUSED
F3	Multiple Whistles Chime (6)	M	F3a_Long_Chime	F3b_Long_Chime_3_Toot	F3c_2tone_Chime_Long	F3d_Chime_Short	F3e_Chime_Fancy	F3f_Long_2_Chime	UNUSED	UNUSED
F4	Brake	M								
F5	Cylinder Cock	T								
F6	Wheel Slip (Sound is only played when F1 is ON)	T								
F7	Coal Shovelling	T								
F8	Injector	T								
F9	Safety Valve	T								
F10	Guards Whistle	M								
F11	Coupling	M								
F12	Carriage Brake Squeal	M								
F13	Flange Squeal	T								
F14	Blower	T								
F15	Door Slamming	M								
F16	Fireman's Breakfast	T								
F17	Blow Down	T								
F18	Westinghouse Pump	T								
F19	Water Fill	T								
F20	Toggle Sound Mode between "Chuffing" and "Coasting"	T								
F21	<b>Aux1</b>	<b>T</b>								
F22	<b>Aux2</b>	<b>T</b>								
F23	<b>Aux 3</b>	<b>T</b>								
F24	<b>Aux 4</b>	<b>T</b>								
F25	<b>Creep Mode</b>	<b>M</b>								
F26	<b>Coupling Mode</b>	<b>M</b>								
F27	<b>Dynamic Brake</b>	<b>M</b>	<b>M = Momentary Action</b>							
F28	<b>AFC Enable</b>	<b>T</b>	<b>T = Toggle On/Off</b>							

Please refer to the main HM7000 Series Decoder Reference Manual for further information